



Dockside Installation

- (1) **POSITION COVER** — Place main section over boom and bow section over bow support with the mast collars oriented toward the mast. Zip both connecting zippers about 2 feet. Note reference tags for proper orientation.
- (2) **UNFOLD BOW SECTION** — Pull bow section forward and start zippers around forestay cones. Close zipper down the center, in front of the bow pulpit.
- (3) **UNFOLD MAIN SECTION** — Pull main section aft and secure topping lift cone. Close zipper down the center to the backstay. Secure backstay cone and close zipper to bottom of cover.
- (4) **CHECK COVER POSITION** — Line up shroud openings. Adjust layout of cover as needed.
- (5) **MAST COLLARS** — Secure mast collars. Main collar first, then bow section collar. Use the long straps to get around mast multiple times, cinching tight, and then "clicking" into receiving buckle. Zip side zippers to the bottom
- (6) **CONES AND COLLARS** — Close zippers around the shrouds. Tie cinch cord tightly.
- (7) **INTERNAL TABS** — Use a short length of line to secure the tabs on the underside of the cover, to a cleat or brace.
- (8) **HULL LINES** — It may be necessary to lines under the hull, where it is possible. Stern ropes may need to go in front of the rudder, at the top of the shaft.
- (9) **PERIMETER ROPE** — It may be helpful to run a rope through the loops around the perimeter and cinch tightly.
- (10) **SANDBAGS** — Tie sandbags to the perimeter loops as necessary.

